

Tabella Canali CB - Frequenza in MHz

Canale	Banda A	Banda B	Banda C	Banda D	Banda E	Banda F		Canale	Banda A	Banda B	Banda C	Banda D	Banda E	Banda F
1	26,065	26,515	26,965	27,415	27,865	28,315		20	26,305	26,755	27,205	27,655	28,105	28,555
2	26,075	26,525	26,975	27,425	27,875	28,325		21	26,315	26,765	27,215	27,665	28,115	28,565
3	26,085	26,535	26,985	27,435	27,885	28,335		22	26,325	26,775	27,225	27,675	28,125	28,575
3 A	26,095	26,545	26,995	27,445	27,895	28,345		23	26,355	26,805	27,255	27,705	28,155	28,605
4	26,105	26,555	27,005	27,455	27,905	28,355		24	26,335	26,785	27,235	27,685	28,135	28,585
5	26,115	26,565	27,015	27,465	27,915	28,365		25	26,345	26,795	27,245	27,695	28,145	28,595
6	26,125	26,575	27,025	27,475	27,925	28,375		26	26,365	26,815	27,265	27,715	28,165	28,615
7	26,135	26,585	27,035	27,485	27,935	28,385		27	26,375	26,825	27,275	27,725	28,175	28,625
7 A	26,145	26,595	27,045	27,495	27,945	28,395		28	26,385	26,835	27,285	27,735	28,185	28,635
8	26,155	26,605	27,055	27,505	27,955	28,405		29	26,395	26,845	27,295	27,745	28,195	28,645
9	26,165	26,615	27,065	27,515	27,965	28,415		30	26,405	26,855	27,305	27,755	28,205	28,655
10	26,175	26,625	27,075	27,525	27,975	28,425		31	26,415	26,865	27,315	27,765	28,215	28,665
11	26,185	26,635	27,085	27,535	27,985	28,435		32	26,425	26,875	27,325	27,775	28,225	28,675
11 A	26,195	26,645	27,095	27,545	27,995	28,445		33	26,435	26,885	27,335	27,785	28,235	28,685
12	26,205	26,655	27,105	27,555	28,005	28,455		34	26,445	26,895	27,345	27,795	28,245	28,695
13	26,215	26,665	27,115	27,565	28,015	28,465		35	26,455	26,905	27,355	27,805	28,255	28,705
14	26,225	26,675	27,125	27,575	28,025	28,475		36	26,465	26,915	27,365	27,815	28,265	28,715
15	26,235	26,685	27,135	27,585	28,035	28,485		37	26,475	26,925	27,375	27,825	28,275	28,725
15 A	26,245	26,695	27,145	27,595	28,045	28,495		38	26,485	26,935	27,385	27,835	28,285	28,735
16	26,255	26,705	27,155	27,605	28,055	28,505		39	26,495	26,945	27,395	27,845	28,295	28,745
17	26,265	26,715	27,165	27,615	28,065	28,515		40	26,505	26,955	27,405	27,855	28,305	28,755
18	26,275	26,725	27,175	27,625	28,075	28,525								
19	26,285	26,735	27,185	27,635	28,085	28,535								
19 A	26,295	26,745	27,195	27,645	28,095	28,545								

Le Frequenze CB vanno da 26 a 28 MHz.

In Italia è autorizzato il solo uso delle frequenze appartenenti alla banda C